


Ignition Switch

Test


- 1. Remove the dashboard lower cover (see next column).
- 2. Disconnect the 7P connector from the floor wire harness.
- 3. Check for continuity between the terminals in each switch position according to the table.



Terminal Position	WHT/ RED (ACC)	WHT/ BLK (BAT-B)	BLU/ WHT (IG2-B)	WHT (BAT-A)	BLK/ YEL (IG1)	WHT (IG2-A)	BLK/ WHT (ST)
O							
I	○	○					
II	○	○	○	○	○	○	
III				○	○		○

Electrical Switch Replacement

- 1. Remove the dashboard lower cover, and disconnect the floor wire harness connectors.



- 2. Disconnect the 7P connector from the floor wire harness.
- 3. Insert the key, and turn it to "0".
- 4. Remove the two screws, and replace the switch.

