

## Differential

### Manual Transmission

Special Tools .....	15-2
Component Location Index .....	15-3
Preset Torque Inspection .....	15-4
Bearing Replacement .....	15-5
Differential	
Disassembly .....	15-6
Reassembly .....	15-7
Oil Seal Removal .....	15-11
Bearing Outer Race Replacement (Clutch Housing Side) .....	15-12
Bearing Preload Adjustment .....	15-12
Oil Seal Installation .....	15-14

### Automatic Transmission

Special Tools .....	15-16
Component Location Index .....	15-17
Preset Torque Inspection .....	15-18
Bearing Replacement .....	15-19
Differential	
Disassembly .....	15-20
Reassembly .....	15-23
Clutch Disc, Clutch Plate	
Replacement .....	15-22
Oil Seal Removal .....	15-25
Bearing Outer Race Replacement (Torque Converter Housing Side) .....	15-26
Bearing Preload Adjustment .....	15-26
Oil Seal Installation .....	15-28