





Headlight High Beam/Dimmer Relay (USA) Test

1. Remove the headlight high beam relay or the dimmer relay (USA) from the under-hood fuse/relay box.
2. Check continuity at the relay terminals.

- There should be continuity between the C and D terminals.
- There should be continuity between the A and B terminals when power and ground are connected to the C and D terminals.
- There should be no continuity between the A and B terminals when power is disconnected.

• Headlight high beam relay

• Dimmer relay (USA)



Headlight Low Beam Relay Test

1. Remove the headlight low beam relay from the under-hood fuse/relay box.
2. Check continuity at the relay terminals.

- There should be continuity between the C and D terminals.
- There should be continuity between the A and B terminals when power and ground are connected to the C and D terminals.
- There should be no continuity between the A and B terminals when power is disconnected.

