


# Stereo Sound System


## Unit Removal

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.


1. Remove the clock (see page [23-233](#)).
2. Remove the two screws behind the clock, then remove the center air vent (see [section 20](#)).



3. Remove the four screws, then remove the center armrest.




4. Take out the ashtray.






5. Remove the five screws and center console panel, then disconnect the 3P connector and 4P connector from the floor wire harness.



6. Remove the four screws, then disconnect the 14P and 30P connectors from the floor wire harness and take out the climate control unit.



7. Remove the four screws, then disconnect the 16P connector, mast antenna lead, and window antenna lead and take out the stereo radio/cassette player.

