

Maintenance

Lubrication points

'97 Model	4-2
'98-99 Models	4-2a
'00 Model	4-2c
'01 Model	4-2d
'02-03 Models	4-2e
'04 Model	4-2g
'05 Model	4-2h

Maintenance Schedule

Normal Conditions

'97 Model	4-4
'98-99 Models	4-4a
'00 Model	4-4c
'01 Model	4-4d
'02-03 Models	4-4e
'04 Model	4-4g
'05 Model	4-4h

Severe Conditions

'97 Model	4-6
'98-99 Models	4-6a
'00 Model	4-6c
'01 Model	4-6d
'02-03 Models	4-6e
'04 Model	4-6g
'05 Model	4-7h