

Body Electrical

*: Read [SRS precautions](#) before working in this area

Special Tools	23-2	Coolant Temperature Gauge		Key-in Reminder System		HID Inverter Unit Replacement	
Troubleshooting		Gauge Test		Ignition Key Switch Test	23-173	('02-05 Models)	23-47e
Tips and Precautions	23-3	'97-99 Models	23-136	Lighting System		HID Bulb Removal	
Five-step		'00-05 Models	23-34c	Component Location Index		('02-05 Models)	23-42e
Troubleshooting	23-5	Sending Unit Test	23-136	'97-01 Models	23-174	HID Lamp System Troubleshooting	
Relay and Control Unit Locations		Engine Oil Pressure Gauge		'02-05 Models	23-35e	('02-05 Models)	23-44e
Front Compartment		Test	23-137	Switches	23-179	Daytime Running Lights (Canada)	
'97-99 Models	23-7	Engine Oil Pressure Warning		Retractable Headlight Control Unit		Replacement	23-196
'00-01 Models	23-2c	System		Input Test	23-180	Front Turn Signal/Front Parking Lights	
'02-05 Models	23-2e	Switch Test	23-137	Daytime Running Lights Control Unit		Replacement	23-197
Dashboard	23-8	Brake Warning System		Input Test (Canada)		Front Side Marker Lights	
Dashboard, Door and		Parking Brake Switch		'97-01 Models	23-182	Replacement	23-197
Floor	23-9	Test	23-138	'02-05 Models	23-40e	Taillights	
Rear Bulkhead	23-10	Fluid Level Switch Test	23-138	Combination Light/Turn Signal Switch		Replacement	23-198
Engine Compartment		Seat Belt Reminder System		Test	23-183	Bulb Replacement	23-198
'97-99 Models	23-12	Seat Belt Switch Test	23-139	Headlight/Turn Signal Switch		Rear Side Marker Lights	
'00-05 Models	23-3c	Low Fuel Indicator		Replacement	23-184	Replacement	23-199
Battery		Indicator Light Test	23-139	Retractor Switch		License Plate Lights	
Component Location Index	23-67	Interlock System		Removal	23-186	Replacement	23-199
Replacement	23-67	*Component Location Index ...	23-140	Test	23-187	Glove Box Light	
Test		Control Unit Input		Bulb Replacement	23-187	Replacement/Test	23-200
'97-98 Model	23-68	Test	23-143	Retractor Motor		Ceiling/Courtesy/Trunk Lights	
'99-05 Models	23-2b	Key Interlock Solenoid Test ...	23-144	Replacement	23-188	Component Location	
Under-dash Fuse/Relay Box		Shift Lock Solenoid	23-145	Headlight Housing		Index	23-201
Removal/Installation	23-70	Parking Pin Switch	23-146	Adjustment	23-189	Ceiling Lights Test	23-203
Ignition Switch		Safety Indicator		Retractor Motor Test	23-190	Ceiling Light Replacement	23-205
Test	23-72	*Component Location		Headlight Relay Test	23-191	Courtesy Light Test/	
Electrical Switch		Index	23-147	Dimmer Relay Test	23-191	Replacement	23-206
Replacement	23-72	Description	23-147	Retractor Relay Test	23-192	Door Switch Test	23-206
Steering Lock Removal/		Indicator Input Test	23-152	Retractor Cut/Taillight		Trunk Light Test/	
Installation	23-73	Troubleshooting	23-154	Relay Test	23-192	Replacement	23-207
Gauge Assembly		Brake Light Failure Sensor		Headlight High Beam/Dimmer Relay		Latch Switch Test/	
Gauge/Terminal Location		Test	23-155	(USA) ('02-05 Models) Test .	23-45e	Replacement	23-207
Index		Roof Lock Switch Test	23-156	Headlight Low Beam Relay Test		Back-up Lights	
'97-99 Models	23-121	Roof Holder Switch Test ...	23-157	('02-05 Models)	23-45e	Component Location	
'00-01 Models	23-29c	A/T Gear Position Indicator		Taillight Relay Test		Index	23-208
'02-05 Models	23-29e	Component Location		('02-05 Models)	23-46e	Test	23-210
*Removal	23-126	Index	23-158	Dimmer Relay (Canada) Test		Brake Lights	
Bulb Locations		Indicator Input Test	23-160	('02-05 Models)	23-46e	Component Location	
'97-01 Models	23-128	A/T Gear Position Switch		Headlights		Index	23-211
'02-05 Models	23-34e	Test	23-162	Description	23-193	Brake Switch Test	23-213
Disassembly	23-129	Replacement	23-163	Adjustment		High Mount Brake Light	
Speedometer/Trip Meter/Odometer		Bulb Replacement	23-163	'97-01 Models	23-194	Test	23-213
Troubleshooting	23-130	Integrated Control Unit		'02-05 Models	23-48e	Replacement	23-214
VSS Replacement	23-133	Input Test	23-166	Headlight Replacement		Rear Spoiler Replacement	23-214
Fuel Gauge		Lights-on Reminder System		'97-01 Models	23-195		
Gauge Test	23-134	Chime Test	23-172	'02-05 Models	23-47e		
Sending Unit Test	23-135			Bulb Replacement			
				'97-01 Models	23-196		
				'02-05 Models	23-49e		

Body Electrical (Cont'd)

Side Marker/Turn Signal/Hazard

Flasher System	
Component Location	
Index	23-215
Description	23-218
Turn Signal/Hazard Relay	
Input Test	23-220
Cancel Unit Input Test	23-221
Hazard Warning Switch	
Replacement	23-222
Hazard Warning Switch	
Test	23-223
Dash Lights Brightness Controller	
Component Location	
Index	23-224
Control Unit Input Test	23-226
Controller Removal	23-227
Controller Test	23-228
Controller Light Bulb	
Replacement	23-228
Entry Light Timer System	
Component Location	
Index	23-229
Foot Well Light	
Replacement	23-231
Clock	
Removal	23-233
Terminals	23-233
Cigarette Lighter	
Replacement	23-235
Relay Test	23-236
Stereo Sound System	
Component Location	
Index	23-237
CD Changer ('04-05 Models)	
Removal	23-32
Unit Removal	23-240
Unit Terminals	23-242
Power Amplifier Relay	
Test	23-242
Power Antenna Motor	
Test	23-243
Replacement	23-244
Antenna Mast	
Replacement	23-244

Antenna Tube	
Replacement	23-246
Front/Rear Speaker	
Replacement	23-247
Foot Well Bass Speaker	
Replacement	23-247
Horns	
*Component Location Index	
'97-01 Models	23-248
'02-05 Models	23-50e
Description	
'97-01 Models	23-248
'02-05 Models	23-50e
Horn Test	
'97-01 Models	23-250
'02-05 Models	23-52e
Relay Test	23-251
High Horn Relay Test	
('02-05 Models)	23-53e
Security/Low Horn Relay Test	
('02-05 Models)	23-53e
*Switch Test	23-251
Trunk Opener	
Component Location Index ..	23-254
Main Switch Test	23-255
Opener Switch Test	23-256
Solenoid Test/Replacement ..	23-256
Power Mirrors	
Component Location Index ..	23-257
Function Test	23-259
Switch Removal	23-260
Switch Test	23-260
Door Mirror	
Test	23-261
Replacement	23-261
Door Mirror Actuator	
Replacement	23-262
Power Door Locks	
Component Location	
Index	
'97-03 Models	23-263
'04-05 Models	23-13g
Troubleshooting	23-265
Control Unit Input Test	
'97-03 Models	23-266
'04-05 Models	23-16g
Driver's Door Actuator	
Test	23-268

Keyless Buzzer	
Test/Replacement	
('04-05 Models)	23-20g
Transmitter Test	
('04-05 Models)	23-21g
Transmitter Programming ..	23-21g
Passenger's Door Actuator	
Test	23-269
Door Lock Switch Test	23-270
Power Windows	
Component Location	
Index	23-271
Description	23-271
Troubleshooting	23-273
Control Unit Input Test	
'97-99 Models	23-274
'00-05 Models	23-39c
Master Switch Test	23-275
Passenger's Switch	
Test	23-276
Replacement	23-277
Master Switch	
Replacement	23-276
Switch Light Bulb	
Replacement	23-277
Driver's Window Motor	
Test	23-278
Passenger's Window Motor	
Test	23-278
Relay Test	23-279
Power Seats	
Component Location	
Index	23-280
Seat Switch Test	23-282
Motor Test	23-283
Rear Window Defogger	
Component Location	
Index	23-284
Description	23-284
Troubleshooting	23-286
Switch Replacement	23-287
Relay Test	23-288
Switch Test	23-289
Function Test	23-290
Defogger Wire Repair	23-290

Wiper/Washers

Component Location	
Index	23-291
Description	23-291
Troubleshooting	23-293
Intermittent Wiper	
Relay Test	23-293
High Relay/Washer	
Relay Test	23-294
Low Relay Test	23-294
Windshield Wiper Motor	
Test	23-295
Replacement	23-296
Windshield Wiper/Washer Switch	
Replacement	23-296
Test	23-298
Washer Replacement	23-299
Washer Motor Test	23-299
Security Alarm System	
Component Location	
Index	23-312
Description	23-314
Wiring Connections	23-320
Troubleshooting	23-321
Control Unit Input Test	
'97-01 Models	23-322
'02-03 Models	23-58e
'04-05 Models	23-26g
Trunk Latch Switch Test	23-325
Door Switch Test	23-325
Indicator Replacement	23-326
Trunk Key Cylinder Switch	
Test	23-326
Engine Compartment Lid	
Switch Test	23-327
Hood Switch Test	23-327
Ignition Key Switch Test	23-328
Immobilizer System	
Component Location	
Index	23-329
Description	23-330
Problems and Replacement	
Parts	23-332
Control Unit Input Test	23-334
Immobilizer Receiver and	
Transponder (Key) Test	23-335
Immobilizer Receiver	
Replacement	23-336