

Idle Control System


Starter Switch Signal

This signals the ECM when the engine is cranking.

Inspection of Starter Switch Signal.



- NOTE:
- M/T: Clutch pedal must be depressed.
 - A/T: Transmission in **N** or **P** position.

Check for an open or short in the wire (STS line):
Measure voltage between ECM connector terminals C6 and A26 with the ignition switch in the start (III) position.



NO

Inspect the No. 7 STARTER SIGNAL (7.5 A) fuse in the underdash fuse box.



- Repair short in the wire between the ECM (C6) and the No. 7 STARTER SIGNAL (7.5 A) fuse or the PGM-FI main relay.
- Replace the No. 7 STARTER SIGNAL (7.5A) fuse.