

CKP/CYP Sensor

Replacement

NOTE: Turn the crankshaft so that the No. 1 piston is at top dead center (see page 6-19).

1. Remove the timing belt (see page 6-15).
2. Remove the front intake and exhaust camshaft pulleys.
3. Remove the back cover.
4. Remove the CKP/CYP sensor from the front cylinder head.

5. Install the CKP/CYP sensor in the reverse order of removal.
 - Refer to page 6-18 and 6-19, when installing the timing belt.

