



# Oil Seal

## Installation

1. Install the oil seal into the transmission housing using the special tools.



2. Install the oil seal into the clutch housing using the special tools.

