MODE CONTROL MOTOR
Replacement, page 22-57 ('93-'96), 69 ('91-'92 Models)
Test, page 22-58 ('93-'96), 91 ('91-'92 Models)

EVAPORATOR TEMPERATURE SENSOR
Removal, page 22-65 ('93-'96), 88 ('91-'92 Models)
Test, page 22-65 ('93-'96), 88 ('91-'92 Models)

SUNLIGHT SENSOR
Removal, page 22-63 ('93-'96), 87 ('91-'92 Models)
Test, page 22-63 ('93-'96), 87 ('91-'92 Models)

HEATER VALVE CABLE
Adjustment, page 22-58 ('93-'96), 91 ('91-'92), 75 ('93-'96), 66 ('91-'92)

CLIMATE CONTROL UNIT
Replacement, page 22-54
Adjustment, page 22-55

COMPRESSOR (NIPPONDENSO)
Compresses the refrigerant and then forces it through the condenser.

"DEF" DOOR
Adjustment, page 22-77 ('92-'96), 72 ('91Models)
"HEAT" DOOR
Adjustment, page 22-77 ('92-'96), 72 ('91Models)

VENT DOOR CONTROL MOTOR
Replacement, page 22-60 ('93-'96), 69 ('91-'92 Models)
Test, page 22-60 ('93-'96), 69 ('91-'92 Models)

RECIRCULATION CONTROL MOTOR
Replacement, page 22-59 ('93-'96), 64 ('91-'92)
Test, page 22-59 ('93-'96), 64 ('91-'92 Models)

BLOWER UNIT
Replacement, page 22-67 ('93-'96), 63 ('91-'92)
Overhaul, page 22-68 ('93-'96), 62 ('91-'92)

RECEIVER/DRYER
Serves as a reservoir which filters and removes moisture from the refrigerant.

A/C TRIPLE PRESSURE SWITCH

IN-CAR TEMPERATURE SENSOR
Removal, page 22-61 ('93-'96), 69 ('91-'92 Models)
Test, page 22-61 ('93-'96), 69 ('91-'92 Models)

HEATER-EVAPORATORUNIT
Replacement, page 22-74 ('93-'96), 66 ('91-'92 Models)
Overhaul, page 22-76 ('93-'96), ('92), 71 ('91 Models)

OUTSIDE AIR TEMPERATURE SENSOR
Removal, page 22-62 ('93-'96), 86 ('91-'92 Models)
Test, page 22-62 ('93-'96), 86 ('91-'92 Models)

DUAL CONDENSER
Dissipates the heat which was absorbed by the refrigerant.
Replacement, page 22-79 ('93-'96), 74 ('91Models)
Overhaul, page 22-80 ('93-'96), 75 ('91Models)

HEATER CORE TEMPERATURE SENSOR
Removal, page 22-64
Test, page 22-64

AIR MIX CONTROL MOTOR
Replacement, page 22-56 ('93-'96), 70 ('91-'92 Models)
Test, page 22-57 ('93-'96), 69 ('91-'92 Models)