

# Transmission Housing



## Removal

**NOTE:**

- Clean all parts thoroughly in solvent or carburetor cleaner, and dry with compressed air.
- Blow out all passages.
- The (7/32) #7 steel ball in the reverse idler gear shaft is under spring pressure. Take care not to let it pop out.

1. Remove the transmission housing in the following numbered sequence.

**CAUTION:** Set the special tool with bolts as shown.



**NOTE:** Remove three shafts together.

