




Carpet

Replacement

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS (section 24) before performing repairs or service.

1. Remove:
 - Seats (see page 20-39)
 - Footrest
 - Under-dash fuse box lid (see page 20-38)
 - Side sill trim (see page 20-38)
 - Side sill pad (see page 20-38)
 - Rear side trim panel (see page 20-38)
 - Center armrest (see page 20-49)
 - Center console panel (see page 20-52)
2. Detach the clips at the front edge (passenger's).
3. Remove the console carpet attaching screw from the heater unit (passenger's).
4. Disconnect the air duct (driver's) and air vent, then remove the carpet hooks from the dashboard inside screws.




(cont'd)

Carpet

Replacement (cont'd)

5. Pull up the retainers, then remove the floor carpets.
6. Remove the console carpets.



7. Installation is the reverse of the removal procedure.

NOTE:

- Take care not to damage, wrinkle or twist the carpets.
- Make sure the air vents are connected, into the heater unit and air duct.
- Make sure the seat harnesses are routed correctly.